



Odor Control Kit Instructions

The Freedom odor control kit is a fast economical way to control fumes generated during the cleaning process. It consists of three Plexiglas panels and a duct adaptor to allow the fumes to be ventilated outside. The design allows that the panels can be easily removed in seconds to allow easy removal of the jars.

Contents:

- Four 1/8" X 1/8" X 40-40 shoulder screws
- One left Plexiglas panel
- One right Plexiglas panel
- One center panel
- One duct adaptor
- Six feet (1.8 meter) of flex hose
- One hose clamp

- 1) Unpack the contents of the shipping box and check that all parts and hardware are accounted for.
- 2) Locate the 4 pan-head screws (2 each side) installed on the lower left and right sides of the Freedom.
- 3) Remove these screws and replace them with the 4 shoulder screws. Do NOT overtighten these screws.
- 4) Remove the protective film from the Plexiglas panels.
- 5) Install the left and right panels by sliding the slots in the panel over the shoulder screws. The magnets hold the top edge in place.
- 6) The front panel simply hangs from the two side panels. Insert the bottom of the front panel first, tilt up and hook the top.

The Duct adaptor may be installed as follows:

- 1) Keep the Freedom upright while installing the duct adaptor. Remove the 4 nuts on the rear of the Freedom. Do not remove the screws from the front of the Freedom.
- 2) Remove the wire guard on the rear of the Freedom. Do not remove the wire guard on the front of the machine or the screws.
- 3) Install the duct adaptor and the four nuts. Do not overtighten the nuts.
- 4) Connect the ductwork to the duct adaptor using the supplied hose clamp
- 5) Route the duct so as to prevent kinks which limit airflow.